

Collecting Radiological

Bottle Requirements

4-Liter plastic cubitainer

Sampling Location

The location code that is identified on the water systems **Sampling Plan**.

Sampling Instructions

- Flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
- Reduce the sample stream and take and record the free residual chlorine as applicable on the COC.
- Label the cubitainer before filling.
- Unscrew the lid, and expand the cubitainer by pulling the two walls apart. Do not inflate the cubitainer by blowing into it. This may contaminate the container (and the sample). Be careful not to touch the bottom of the sample lid, or the inside of the cubitainer.
- Rinse the inside before filling. Pull up on the neck of the cubitainer until it “pops” and stays in the “up” position.
- Fill the cubitainer by holding it under the flowing water. Leave a small volume of air inside the cubitainer (headspace) and screw the lid on tightly.
- Fill out the COC.



3 Locations in Oklahoma

Accurate – Stillwater

505 South Lowry Street Stillwater, OK 74074
Fax (405) 372-5396

Accurate – Tulsa

3910 E. 51st Street Tulsa, OK 74135
Fax (918) 663-6300

Accurate – OKC

12036 North Penn Ave. Okla. City, OK 73120
Fax (405) 751-3108

Need a quote or have questions?

*Call our toll free number (800) 516-LABS
or visit www accuratelabs.com*