

Collecting Wet Chem, Metals, & Organic (Soil/ Sludge/Solids)

Bottle Requirements

2-4oz or 1-8 oz glass non-preserved bottles
Full TCLP samples require, minimum of 100 grams.



Sampling Instructions

1. Completely fill the container with sample.
2. Label the sample bottles and fill out the COC.
3. All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.

**Accurate
Environmental**

Engineering Services
Environmental Training
Laboratory Supplies
Analytical Laboratories

(800) 516 LABS (5227)
www.accuratelabs.com

3 Locations in Oklahoma

Accurate – Stillwater

505 South Lowry Street Stillwater, OK 74074
Fax (405) 372-5396

Accurate – Tulsa

3910 E. 51st Street Tulsa, OK 74135
Fax (918) 663-6300

Accurate – OKC

12036 North Penn Ave. Okla. City, OK 73120
Fax (405) 751-3108

Need a quote or have questions?

*Call our toll free number (800) 516-LABS
or visit www.accuratelabs.com*