

Instructions for EPA Method 1664A

Bottle Requirements

Clear 1 L with H₂SO₄

Sampling Location

The location code that is identified on the water systems

Sampling Plan.

Sampling Instructions

Take caution with the preservative sulfuric acid is acidic.

- Flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
- Reduce the sample stream and take and record the free residual chlorine as applicable on the COC.
- Fill the bottles for the analysis to their shoulder. Cap and mix the samples.
- Label the sample bottles and fill out the COC.
- All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.



Note: Holding Time is 28 days.

Accurate Environmental

Engineering Services
Environmental Training
Laboratory Supplies
Analytical Laboratories

(800) 516 LABS (5227)
www accuratelabs.com

3 Locations in Oklahoma

Accurate – Stillwater

505 South Lowry Street Stillwater, OK 74074
Fax (405) 372-5396

Accurate – Tulsa

3910 E. 51st Street Tulsa, OK 74135
Fax (918) 663-6300

Accurate – OKC

12036 North Penn Ave. Okla. City, OK 73120
Fax (405) 751-3108

Need a quote or have questions?

*Call our toll free number (800) 516-LABS
or visit www accuratelabs.com*