

Collecting EPA 200.8 Lead and Copper

Bottle Requirements

1000mL plastic bottle (unpreserved)

Sampling Location

The location code that is identified on the water system Sampling Plan.

Sampling Instructions

1. Collect samples in the morning before using water for the day.
2. Fill the bottles for the analysis to their shoulder. Cap and mix the samples.
3. Label the sample bottles and fill out the COC.
4. Deliver to the lab the same day that they are taken if possible.



Note:

- *Lead and Copper samples for compliance must be in 1000 ml containers, and the hold time is 14 days.*
- *The COC must have SDWIS # on it and location code to be submitted to DEQ*

Accurate Environmental

Engineering Services
Environmental Training
Laboratory Supplies
Analytical Laboratories

(800) 516 LABS (5227)
www.accuratelabs.com

3 Locations in Oklahoma

Accurate – Stillwater

505 South Lowry Street Stillwater, OK 74074
Fax (405) 372-5396

Accurate – Tulsa

3910 E. 51st Street Tulsa, OK 74135
Fax (918) 663-6300

Accurate – OKC

12036 North Penn Ave. Okla. City, OK 73120
Fax (405) 751-3108

Need a quote or have questions?

*Call our toll free number (800) 516-LABS
or visit www.accuratelabs.com*