

Collecting Hexavalent Chromium EPA 218.7

Bottle Requirements

125ml HDPE plastic WM, pH>8 w/
buffer

Sampling Instructions

1. Label the sample bottles and fill out the COC.
2. If sampling from tap flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
3. Fill the bottles for the analysis to their shoulder. Cap and mix the samples.
4. All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.

Note: Holding time is 5 days unless frozen.



3 Locations in Oklahoma

Accurate – Stillwater

505 South Lowry Street Stillwater, OK 74074
Fax (405) 372-5396

Accurate – Tulsa

3910 E. 51st Street Tulsa, OK 74135
Fax (918) 663-6300

Accurate – OKC

12036 North Penn Ave. Okla. City, OK 73120
Fax (405) 751-3108

Need a quote or have questions?

*Call our toll free number (800) 516-LABS
or visit www.accuratelabs.com*