

## Collecting EPA 353.2 /300.0 Nitrate & Nitrite



EPA Method 353.2



EPA Method 300.0

### **Bottle Requirements**

500 ml H<sub>2</sub>SO<sub>4</sub> (Sulfuric acid) or  
500 ml plastic (unpreserved)

### **Sampling Instructions**

*Take caution with the preservative –it is Acidic*

1. Label the sample bottles and fill out the COC.
2. Flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
3. Fill the bottles for the analysis to their shoulder. Cap and mix the samples.
4. All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.

*Note: Holding time is 48 hours for non-preserved sample.*



### 3 Locations in Oklahoma

#### **Accurate – Stillwater**

505 South Lowry Street Stillwater, OK 74074  
Fax (405) 372-5396

#### **Accurate – Tulsa**

3910 E. 51<sup>st</sup> Street Tulsa, OK 74135  
Fax (918) 663-6300

#### **Accurate – OKC**

12036 North Penn Ave. Okla. City, OK 73120  
Fax (405) 751-3108

*Need a quote or have questions?*

*Call our toll free number (800) 516-LABS  
or visit [www.accuratelabs.com](http://www.accuratelabs.com)*