

## Collecting EPA Method 314.0 Perchlorate



### **Bottle Requirements**

2-40ml amber glass (unpreserved) or  
500 ml plastic (unpreserved)

### **Sampling Instructions**

1. Label the sample bottles and fill out the COC.
2. Flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
3. Fill the bottles for the analysis to their shoulder. Cap and mix the samples.
4. All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.

*Note: Holding time is 28 days.*

**Accurate  
Environmental**

Engineering Services  
Environmental Training  
Laboratory Supplies  
Analytical Laboratories

**(800) 516 LABS (5227)**  
[www.accuratelabs.com](http://www.accuratelabs.com)

### 3 Locations in Oklahoma

#### **Accurate – Stillwater**

505 South Lowry Street Stillwater, OK 74074  
Fax (405) 372-5396

#### **Accurate – Tulsa**

3910 E. 51<sup>st</sup> Street Tulsa, OK 74135  
Fax (918) 663-6300

#### **Accurate – OKC**

12036 North Penn Ave. Okla. City, OK 73120  
Fax (405) 751-3108

*Need a quote or have questions?*

*Call our toll free number (800) 516-LABS  
or visit [www.accuratelabs.com](http://www.accuratelabs.com)*