

Collecting EPA 531.1 Pest/Carbamates



Bottle Requirements

2-40 ml VOA preserved with $\text{Na}_2\text{S}_2\text{O}_3$ /MCAA

Sampling Location

The location code that is identified on the water system **Sampling Plan**.

Sampling Instructions

1. Flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
2. Reduce the sample stream.
3. Fill the two 40ml VOA. Cap tightly and shake to ensure the preservative is dissolved.
4. Trip Blanks are supplied with sample containers; they should be kept with the containers supplied for sampling.
5. All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.

Note:

- *Holding Time is 7 days.*
- *Protect containers from light.*



3 Locations in Oklahoma

Accurate – Stillwater

505 South Lowry Street Stillwater, OK 74074
Fax (405) 372-5396

Accurate – Tulsa

3910 E. 51st Street Tulsa, OK 74135
Fax (918) 663-6300

Accurate – OKC

12036 North Penn Ave. Okla. City, OK 73120
Fax (405) 751-3108

Need a quote or have questions?

*Call our toll free number (800) 516-LABS
or visit www.accuratelabs.com*