

## Collecting EPA 547 Glyphosate

### **Bottle Requirements:**

2-40 ml VOA preserved with Na<sub>2</sub>S<sub>2</sub>O<sub>3</sub>

### **Sampling Location:**

The location code that is identified on the water system **Sampling Plan**.

### **Sampling Instructions:**

1. Flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
2. Reduce the sample stream.
3. Fill the two 40ml VOA. Cap tightly and shake to ensure the preservative is dissolved.
4. Trip Blanks are supplied with sample containers; they should be kept with the containers supplied for sampling.
5. All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.

#### **Note:**

- *Holding Time is 7 days.*
- *Protect containers from light.*



**Accurate  
Environmental**

Engineering Services

Environmental Training

Laboratory Supplies

Analytical Laboratories

**(800) 516 LABS (5227)**  
[www accuratelabs.com](http://www accuratelabs.com)

### 3 Locations in Oklahoma

#### **Accurate – Stillwater**

505 South Lowry Street Stillwater, OK 74074  
Fax (405) 372-5396

#### **Accurate – Tulsa**

3910 E. 51<sup>st</sup> Street Tulsa, OK 74135  
Fax (918) 663-6300

#### **Accurate – OKC**

12036 North Penn Ave. Okla. City, OK 73120  
Fax (405) 751-3108

*Need a quote or have questions?*

*Call our toll free number (800) 516-LABS  
or visit [www accuratelabs.com](http://www accuratelabs.com)*