

Collecting EPA 548.1 Endothall

Bottle Requirements

4-4 oz Amber Glass Jars preserved with $\text{Na}_2\text{S}_2\text{O}_3$

Sampling Location

The location code that is identified on the water system Sampling Plan.



Sampling Instructions

1. Flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
2. Reduce the sample stream.
3. Fill the four 4 oz Amber Glass Jars. Cap tightly and shake to ensure the preservative is dissolved.
4. Label the sample bottles and fill out the COC.
5. All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.

Note: Holding Time is 7 days.



3 Locations in Oklahoma

Accurate – Stillwater

505 South Lowry Street Stillwater, OK 74074
Fax (405) 372-5396

Accurate – Tulsa

3910 E. 51st Street Tulsa, OK 74135
Fax (918) 663-6300

Accurate – OKC

12036 North Penn Ave. Okla. City, OK 73120
Fax (405) 751-3108

Need a quote or have questions?

*Call our toll free number (800) 516-LABS
or visit www.accuratelabs.com*