

Collecting EPA Method
Pest 608/614/619/622/8081/8082/8141,
Herb 615/8151,
SVOC 625/8270

Bottle Requirements

4-amber 1 L with Na₂S₂O₃



Sampling Instructions

1. Fill the 1 Liter bottles to the neck, do not over flow. Cap and mix the samples.
2. Label the sample bottles and fill out the COC.
3. Samples need to be kept at 4°C and if possible, delivered to the lab the same day that they are taken.

Note: Holding Time is 7 days.



**Accurate
Environmental**

Engineering Services
Environmental Training
Laboratory Supplies
Analytical Laboratories

(800) 516 LABS (5227)
www.accuratelabs.com

3 Locations in Oklahoma

Accurate – Stillwater

505 South Lowry Street Stillwater, OK 74074
Fax (405) 372-5396

Accurate – Tulsa

3910 E. 51st Street Tulsa, OK 74135
Fax (918) 663-6300

Accurate – OKC

12036 North Penn Ave. Okla. City, OK 73120
Fax (405) 751-3108

Need a quote or have questions?

*Call our toll free number (800) 516-LABS
or visit www.accuratelabs.com*