

Method Analyte Lists for 537, 537.1 and 533

EPA 537

PFOA
PFOS
PFNA
PFHxS
PFHpA
PFBS

EPA 537.1

PFOA NMeFOSAA
PFOS NEtFOSAA
PFNA PFTrDA
PFHxS PFTA
PFHpA
PFBS

EPA 533

PFOA	PFBA	4:2FTS	PFHpS	PFDaA
PFOS	PFMPA	PFHxA	9Cl-PF3ONS	
PFNA	PFPeA	PFPeS	8:2FTS	
PFHxS	PFMBA	HFPO-DA	PFDA	
PFHpA	PFEESA	ADONA	PFUnA	
PFBS	NFDHA	6:2FTS	11Cl-PF3OUdS	

Contact Us

Phone: (405) 372-5300 or (800) 516-LABS (5227)

Email: Dannv@accuratelabs.com

Web: www.accuratelabs.com

EPA Method 537, 537.1, & 533 Sampling



250 mL plastic containers for PFAS sampling.

ACCURATE ENVIRONMENTAL LABS



EPA Method 537, 537.1, & 533 in drinking water.

We can process other types of water, screen soil samples.

Please call the lab if you have any questions about analyte lists or methods. Also, there is a table on the back of this sampling sheet with the current analyte lists. This list may change without notice.

Our normal turnaround is 10 business days at a cost of \$420 per sample. Return shipping to the lab is not included. Field blanks can be sent at an additional cost of \$420 each. Discounts can be given for 20 or more samples, contact Danny Chance for pricing.

Sample contamination can be caused by:

- Lotions, cosmetics, sunscreen, insect repellents.
- Tyvek suits, weatherproof treated clothing
- New or unwashed clothing
- Prepacked foods
- Unwashed hands
- Aluminum foil
- Post-it notes
- Teflon or any PTFE product (tubing or bailer)

What is safe to use?

- HDPE equipment
- Stainless Steel equipment
- Nitrile Gloves
- Wash hands thoroughly
- Trip or Field Blanks can be obtained from the lab to check for contamination during sampling or shipping.

Sampling instructions:

Samples should be collected before any filtration, preferable directly from the well. Do not use any hoses or tubing for sampling.

- **FIELD BLANKS:** Locate the two Field Blank Water container. This is certified PFAS free lab water. Transfer the water to the preserved Field Blank containers (2) filling them completely to the top without overflowing. These are now your field blanks. [Keep the Field Blanks in separate Zip-loc bags, away from field samples.](#)
- Locate sample containers. Fill the sample container completely to the top with sample (there may be either 2 or 4 depending on the QC needed by the lab). **Do not overflow.**
- Immediately place the samples on ice in the cooler they were received in. Samples need to be kept on ice at less than 6°C.
- When shipping samples, the cooler must be filled completely with ice and sent overnight with AM delivery.
- Make sure all labels and Chain of Custody (COC) are filled out completely with dates, times & location.
- Place completed and signed COCs back into the supplied zip lock bag. Seal the bag and tape to the underside of the cooler lid or on the outside of the cooler.